

Eliminator[®] LIGHTING

E 134 **Star Blast**

CAUTION! Please read and understand these instructions before installing or operating this unit.

SPECIFICATIONS:

Model:	E 134
Lamp:	LL-64514 120V/300W
Weight:	3lbs./ 1.36kgs.
Size:	9" (L) x 7" (W) x 6.2" (D)
Fuse:	5 Amp
Supply Voltage:	120V
Working Position:	Any Safe position
Duty Cycle:	None
Color Lenses:	Multi-Colored
Warranty:	1 Year Limited Warranty

Introduction:

The E 134 has been tested and the lamp has been installed at the factory, there is no assembly required. The unit is ready to be plugged in to a power outlet. This unit is a lightweight 4 unit in-sync system. Up to 16 units can be connected together. It runs as a stand-alone, system powered by 1 master unit and 3 slave units. The system comes with 16 sound activated patterns. To enhance the beams use this effect with a fog machine. This unit also looks great in pairs.

Operating Instructions:

Using the provided cables, link the units together. On the side of each unit, you will find a unit selector knob. With this selector knob, designate which head is unit 1, unit 2, unit 3 and unit 4. The units will now chase in that order. On the Master unit is mode selector knob. You can choose between, chase mode, sound active mode, flash mode, all on mode, or 16 patterns

Caution! Never open unit when in use. Always disconnect main power before serving or replacing lamp. Remember to always replace with the exact same type lamp and fuse.

HALOGEN LAMP WARNING!

This fixture is fitted with halogen lamps which are highly susceptible to damage if improperly handled. Never touch lamp with bare fingers as the oil from your hands will shorten lamp life. Also, never move fixture until lamp has had ample time to cool. Remember, lamps are not covered under warranty conditions.

Lamp Replacement: Disconnect the units main power supply. Unscrew and remove the three phillips screws that secure the outer half of the dome cover to the inner half. Remove the outer half of the dome assembly to expose the lamp. Remove and replace the bulb. Reassemble and reconnect the power supply. Be sure to follow all the handling instructions that are included with your new lamp.

1 Year Limited Warranty: Eliminator Lighting warranty is valid from the date of purchase. Our 1 year limited warranty covers manufacturing defects only. Serial number, place of purchase with dated valid receipt must be submitted at time of service. Eliminator Lighting warranty does not cover items or parts prone to wear and tear: lamps, fuses, brushes and belts. Eliminator Lighting warranty is only valid with-in the United States.